

消耗件更换保养套餐

202401ver.

	Df	D5	D6	D500	D610	D750	D780	D810 D810A	D850	D7500
快门组件	●	●	●	●	●	●	●	●	●	●
SQ组件	-	-	●	●	●	●	●	●	●	●
小主体	●	●	●	-	-	●	-	-	-	-
后背饰皮	●	-	-	●	●	●	●	●	●	●
侧饰皮	●	●	●	●	-	●	●	●	●	●
握手饰皮	●	●	●	●	-	●	●	●	-	-
下饰皮	-	●	●	-	-	-	-	-	-	-
底部饰皮	●	●	●	-	-	-	-	●	-	-
顶盖饰皮	●	-	-	-	-	-	-	-	-	-
卡盖饰皮	-	●	●	-	-	-	-	●	●	-

	Z 5	Z 6	Z 6II	Z 7	Z 7II	Z 8	Z 9	Z 30	Z 50	Z fc	Z f
快门组件	●	●	●	●	●	-	-	●	●	●	●
机身卡口	●	●	●	●	●	●	●	●	●	●	●
机身卡口弹簧片	●	●	●	●	●	●	●	●	●	●	●
后背饰皮	-	-	-	-	-	-	●	●	●	●	●
侧饰皮	-	●	●	●	●	●	●	●	●	●	●
握手饰皮	●	●	●	●	●	●	●	●	●	●	●
下饰皮	-	-	-	-	-	-	●	-	-	-	-
底部饰皮	-	-	-	-	-	-	●	-	-	-	-
顶盖饰皮	-	-	-	-	-	-	-	-	-	●	●
卡盖饰皮	-	-	●	-	●	●	●	-	-	-	-

消耗件更换保养套餐

202401ver.

	AF-S NIKKOR 14-24mm f/2.8G ED	NIKKOR Z 14-24mm f/2.8 S	NIKKOR Z 14-30mm f/4 S	AF-S NIKKOR 24-70mm f/2.8E ED VR	AF-S NIKKOR 70-200mm f/2.8E FL ED VR	NIKKOR Z 24-70mm f/2.8 S	NIKKOR Z 24- 70mm f/4 S
镜头卡口	●	●	●	●	●	●	●
马达	●	-	●	●	●	●	●
光圈	●	●	-	●	●	●	●
触点	●	●	●	●	●	●	●
对焦环饰皮	●	●	-	●	●	-	-
变焦环饰皮	●	●	●	●	●	●	●
饰皮	-	-	-	-	●	-	-

	NIKKOR Z 24- 120mm f/4 S	NIKKOR Z 70-200mm f/2.8 VR S	NIKKOR Z 100-400mm f/4.5-5.6 VR S	NIKKOR Z 70- 180mm f/2.8	NIKKOR Z 180-600mm f/5.6-6.3 VR	NIKKOR Z DX 12-28mm f/3.5-5.6 PZ VR	NIKKOR Z 17- 28mm f/2.8
镜头卡口	●	●	●	●	●	●	●
马达	●	●	●	●	●	●	●
光圈	●	●	●	●	●	●	●
触点	●	●	●	●	●	●	●
对焦环饰皮	●	●	●	-	-	-	-
变焦环饰皮	●	●	●	●	●	-	●
饰皮	-	●	-	-	●	-	-

	NIKKOR Z 20mm f/1.8 S	NIKKOR Z 24mm f/1.8 S	NIKKOR Z 35mm f/1.8 S	NIKKOR Z 50mm f/1.2 S	NIKKOR Z 50mm f/1.8 S	NIKKOR Z 58mm f/0.95 S	NIKKOR Z 85mm f/1.2 S	NIKKOR Z 85mm f/1.8 S
镜头卡口	●	●	●	●	●	●	●	●
马达	●	●	●	●	●	-	●	●
光圈	●	●	●	●	●	-	●	●
触点	●	●	●	●	●	●	●	●
对焦环饰皮	-	-	-	●	-	-	●	-
变焦环饰皮	-	-	-	-	-	-	-	-
饰皮	-	-	-	●	-	-	●	-

	NIKKOR Z MC 105mm f/1.8 VR S	NIKKOR Z 400mm f/2.8 TC VR S	NIKKOR Z 400mm f/4.5 VR S	NIKKOR Z 600mm f/4 TC VR S	NIKKOR Z 800mm f/6.3 VR S	NIKKOR Z DX 24mm f/1.7	NIKKOR Z 26mm f/2.8	NIKKOR Z 40mm f/2 (SE)
镜头卡口	●	●	●	●	●	●	●	●
马达	●	●	●	●	●	●	-	●
光圈	●	●	●	-	●	●	●	●
触点	●	●	●	●	●	●	●	●
对焦环饰皮	●	●	●	●	●	-	-	●
变焦环饰皮	-	-	-	-	-	-	-	-
饰皮	●	●	-	●	●	-	-	-

	NIKKOR Z 135mm f/1.8 S Plena	NIKKOR Z 600mm f/6.3 VR S
镜头卡口	●	●
马达	●	●
光圈	●	●
触点	●	●
对焦环饰皮	●	●
变焦环饰皮	-	-
饰皮	-	●

消耗件更换保养套餐

202401ver.

	SB-R200	SU-800	SB-5000	SB-700	SB-500
热靴	-	●	●	●	●
灯管	●	●	●	●	●
闪光灯面板	●	●	●	●	●
内置反射卡	-	-	●	●	-
内置宽面板	-	-	●	●	-
闪光灯头锁定解除按钮橡胶	-	-	●	●	-
闪光灯头锁定解除按钮另一侧橡胶	-	-	●	●	-
AF辅助照明面板	-	●	●	●	●
外接电源端子盖	-	-	●	-	-
同步端子盖	●	-	●	●	-